

Maintenance and handover record

CenoBots L4 | Routine maintenance and functional checks

01 / Identification and water-system service

Service record no.	Service date	Start / end time	Technician
Customer / site	Site contact		
Address / service area			

Model / hardware version	Serial number	Software / operating hours
--------------------------	---------------	----------------------------

Agreed scope

☐ Routine service ☐ Fault investigation ☐ Annual items (attach applicable plan and records)

Select one result per row: OK = completed, satisfactory; NOK = checked, defect found; NP = not completed / unverified; NA = not applicable. Explain NOK, NP and NA on page 3. Record retest results separately; retain the original finding.

A Preparation and identification

ID	Check / completion criterion	OK	NOK	NP	NA	Action / ref.
A01	Model, serial number and installed options match the job; service scope recorded.	☐	☐	☐	☐	
A02	Record initial alarms, condition and existing damage; assign photo references.	☐	☐	☐	☐	
A03	Raise assemblies if needed, then complete normal shutdown; water collection and cleaning tools ready.	☐	☐	☐	☐	
A04	Drain the relevant tank before filter removal; identify connections, circuit and fitted version.	☐	☐	☐	☐	

B Tanks, filters and hoses

ID	Check / completion criterion	OK	NOK	NP	NA	Action / ref.
B01	Recovery tank, lid and sealing face cleaned; no visible damage; lid seats correctly.	☐	☐	☐	☐	
B02	Empty, clean and refit the yellow-framed debris bag; mesh has no tears.	☐	☐	☐	☐	
B03	Grey recovery-tank filter cleaned, checked and refitted; screen unobstructed and intact.	☐	☐	☐	☐	
B04	Clean the blue float cage and level parts in place as shown; use no unverified removal method.	☐	☐	☐	☐	
B05	Clean solution tank and grey in-tank filter; check connection and seal; refit filter.	☐	☐	☐	☐	
B06	Lower blue-framed mesh: confirm fitment and cup procedure first; clean mesh/cup and check seal. If unconfirmed, mark NP.	☐	☐	☐	☐	
B07	If fitted, service the matching V1.3 recovery-filter cup and restore its valve position; identify separately from B06.	☐	☐	☐	☐	
B08	Flush vacuum hose using the manual vacuum procedure; check drains, stoppers and connections.	☐	☐	☐	☐	

Before B06: the lower blue-framed mesh is separate from the recovery-tank float cage. If L4 fitment or cup/housing removal is unconfirmed, mark NP and log an action. Do not transfer L3 or another filter's valve procedure.

Maintenance and handover record

CenoBots L4 | Routine maintenance and functional checks

02 / Mechanical, power and functional checks

Service record no. _____

Serial number _____

Select one: OK satisfactory; NOK defect; NP incomplete/unverified; NA not applicable. Explain NOK, NP and NA on page 3.

C Brushes, squeegee and mechanical parts

ID	Check / completion criterion	OK	NOK	NP	NA	Action / ref.
C01	Clean brushes/pads; check wear indicators, even wear and entangled debris.	☐	☐	☐	☐	_____
C02	Clean and seat brush couplings correctly; record type and quantity if replaced as a pair.	☐	☐	☐	☐	_____
C03	Clean squeegee and blades; check cuts, hardening and distortion; record reversal/replacement.	☐	☐	☐	☐	_____
C04	Squeegee knobs, clips and vacuum-hose connection secure and correctly fitted.	☐	☐	☐	☐	_____
C05	Skirts intact and unobstructed; if fitted, inspect antistatic-strip mounting and ground contact.	☐	☐	☐	☐	_____
C06	Visible wheels, hubs and moving areas free of debris, obvious damage and looseness.	☐	☐	☐	☐	_____
C07	Inspect housing, covers and visible wiring; no missing fixings, trapped wiring or interference.	☐	☐	☐	☐	_____

D Sensors, power and software status

D01	Clean LiDAR/camera surfaces with a dry microfibre cloth; check obstruction and visible damage.	☐	☐	☐	☐	_____
D02	Inspect charging contacts and visible battery/power parts; record dirt, corrosion or abnormal condition.	☐	☐	☐	☐	_____
D03	Record software version and alarms; update only under a confirmed plan with a separate record.	☐	☐	☐	☐	_____

E Reassembly and functional verification

E01	Filters, seals, covers, stoppers and valves restored to correct operating positions.	☐	☐	☐	☐	_____
E02	Static leak check after filling; no visible leakage at cups, joints, hoses or tanks.	☐	☐	☐	☐	_____
E03	Test water delivery at the brushes in manual mode; record absent or visibly uneven flow.	☐	☐	☐	☐	_____
E04	Brush rotation and brush/squeegee lift function correctly, without jamming or abnormal noise.	☐	☐	☐	☐	_____
E05	Short cleaning test: effective pickup, no obvious streaks or residual water; record test details.	☐	☐	☐	☐	_____
E06	Check low-speed travel, steering and stop response in a safe clear area.	☐	☐	☐	☐	_____
E07	If a workstation is fitted: test docking, charging, refill and draining; note unavailable functions.	☐	☐	☐	☐	_____
E08	Recheck alarms, noise and outstanding issues; account for tools and leave robot/site tidy.	☐	☐	☐	☐	_____

Maintenance and handover record

CenoBots L4 | Routine maintenance and functional checks

03 / Test record, findings and handover

Service record no.

Serial number

On-site test record

Test area / floor / mode

Duration / water delivery / pickup

Battery before/after / charging state

Photo / log / attachment references

Findings, open items and non-applicable items

Ref. / check ID	Finding / reason	Action / retest result	Owner / due date
M01			
M02			
M03			

Consumables and replacement parts

Part / number	Qty.	Action / reason	Post-fit check / ref.

Periodic items and service conclusion

Periodic/annual items: ☐ outside scope ☐ completed per attached record ☐ due/unconfirmed items remain (see findings).

Plan/attachment ref.: _____

Cleaning alone does not complete annual service. Due motor, lift and other periodic work follows the applicable manual and qualified-personnel requirements.

☐ Agreed work complete, no known outstanding defect

☐ Complete with follow-up items handed over

☐ Incomplete / use restricted (explain)

Open items / restrictions / next action

Signatures acknowledge handover of the recorded work, results and open items. Unchecked items are not deemed passed.

Technician name / signature / date

Customer representative / signature / date

Basis: linked L4 guide and source videos; L4 user manual 2024.07, maintenance card V1.3; structure adapted from the existing ERC annual checklist. No unverified disassembly method is specified.

<https://xw-tech.de/erc/cenobots/guides/l4-maintenance/>